
## **DOUBLE "V" RAIL GATE PLAN** Single Gate Configuration - Tapered Top Rail

(10 FOOT WIDE 48" HIGH GATES) CENTRAL EYE HINGES (Product Codes #8312) GATE HUNG BETWEEN POSTS





Distance between latch post and gate	А
Width of Gate	В
Distance between gate and hinge post	С
Total distance between posts	D

		Hardware Required					
	Galvanized Finish	Black Powder Coat over Galvanized Finish	Central Eye Hinge Advantages				
Hinge Set	8312-S242	8312-S24P					
-		Set Includes	Opens both ways 100 degrees				
All fasteners are included	one 24 inch double strap (8312-542 or 8312-54SP)			Incredible amount of adjustment			
with the hardware sets	one adjustable bottom gate fitting (8250-002 or 8250-00P)		Easy operation				
	two 12" adjustable gate pin (8800-122 or 8800-12P)			Very strong			
	Central Latch Option		Dimensions (feet and inches)				
			А	В	С	D	
Quick Catch (shown above)	4100-3SS	4100-3BSS	1.5"	10'	4.5"	10'-6"	
Spring Latch	8327-002	8327-00P	4"	10'	4.5"	10'-8.5"	
Slide Bolt Latch	5002-L122	5002-L12SP	1"	10'	4.5"	10'-5.5"	
***Irish Gate Latch	8328-002	8328-00SP	1"	10'	4.5"	10'-5.5"	
		Lumber Required					
Posts	2 of 8' x 6" x6" (usually dressed out	at 5.5" x 5.5")					
		1" thick by 5.5" wide lumber (commonly stocked decking n					
	at we needed to the 2.5" width dimens	ion for most of the gate and in the process removed any p	prefinished	l, rounde	d corner	s	
Top Rail(tapered)	3 of 10' x 1" x 5.5"						
Rails	2 of 10' x 1" x 5.5" (cut to 2.5" x 10')						
Stiles	3 of 4' x 1" x 5.5" (2 x 5" wide for the hinge side and 2 x 2.5" wide for the latch side)						
Diagonals	1 of 12' x 1" x 5.5" (cut to 2.5" x 6')						
Filler Pieces	use off cuts from other pieces for all	l filler pieces					
		Fasteners Required					
		15 of 2.5" carriage bolts with nuts and washers & 40 of 1."	75" wood s	screws)			
Optional Hold Back - Use a 12	2" Cabin Hook (4270-122 or 4270-12SF	P) if you require a means of keeping the gate open					
*** - In order to use the Irish Ga	te Latch on this gate with its 2.5" stile y	you will need to cut 2" off the latch bolt - a great option but	extra wor	k for the	gate bui	der	


**SNUG COTTAGE HARDWARE** 

Download includes this materials list, component cutting and layout sheet, tips on installing gate posts, and detailed instructions. For a complete listing of our free gate plans and gate layouts visit hooverfence.com.






FIRST LAYER



SECOND LAYER



THIRD LAYER

BUILDING STEPS

