

Halo Kit Installation Instructions

Hoover Fence Company, Rev. 2005

- 1) Nail a string to the back tip of home plate, and proceed out 13 feet in a semi-circle, (Repeat step 1 for outside circumference at 18 or 23-foot mark)
- 2) Start bender board forms at 3 feet from foul line and pour concrete 5 or 10 feet accordingly. **POUR EXACTLY 5 OR 10 FEET TO PREVENT TRIMMING!**
- 3) Concrete needs to be 4-6 inches deep with adequate structural support for climate changes.
- 4) Let concrete cure a minimum of two weeks. (Moisture will ruin glue if concrete is not fully cured!)
- 5) Match pieces to fit diagram, and weigh down center piece in place.
- 6) Use heavy weight to make sure turf lies perfectly still! Then proceed in folding one half section up at a time for glue application.
- 7) Glue each one/half section at a time, each time using 50 or 100 pound rollers afterward for proper adhesive bond. (repeat step 6 and 7 for each section)
- 8) Make sure glue has 24 hours to dry by covering with plastic or field cover.

***** Turn OFF all watering systems for at least 2 days! *****

Notes: Halo with wings can be modified to be 5 or 10 feet long. The wings run along the base line, not in the baseline.

