

Part #6200 Electrified Control Trim Handle For Detex Bar



Install adjustable mounting plate onto gate. Drill hole to allow for wiring from control trim handle



Attach lockbox onto mounting plate using two countersunk screws.



Install Detex subassembly on inside of gate using two ¼" x 1" long machine screws into lever assembly. **NOTE:** Cylinder tail piece must *not* extend past movable cam piece on subassembly.



Installed control handle.
**Handed - need to specify



Install exit bar as shown in other instruction sheet. Electrical connection is made here.



Electrical wiring needs to be run inside exit bar. Exit bar will come apart by loosening set screw and removing. Wiring can be placed in channel. **NOTE-** Additional wiring will need to be run from exit bar to access control reader.