

Bumper Post Sleeve Installation



1.

Quick!



2.

Easy!



3.

Permanent!

Bumper Post Sleeve Quick and Easy Installation

1. Slide sleeve over existing post to see how well the sleeve fits.

**Sleeve inside diameter is always larger than sleeve size. For example, a 6" sleeve has an actual inside diameter of 7".*

2. Apply neoprene adhesive tape approximately 3" down from the top of the post and 3" up from the bottom of the post (tape provided). If a tighter fit is needed, slightly overlap tape directly underneath existing tape. Use one continuous piece of tape.

**Tape length will vary according to post diameter.*

3. With a twisting motion, slowly slide the sleeve over the existing post. If this is done right, you should hear air seeping out between the post and the sleeve.

**If the above directions are followed correctly, the Ideal Sleeve should fit tight with no gap between the pipe and sleeve. The Ideal Sleeve will not be easily removed.*