4612 Brutus Gate Spring TORSION FUNCTION

CORRECT



The Brutus Gate Spring is designed to apply a "torsion" force to your gate and close it. It is meant to be wound to apply force and not stretched. This means that when installed correctly, as pictured above, the act of opening the gate will further wind and/or twist the spring. When you let go of the gate the spring will want to return to its resting position.

INCORRECT



Pictured above is an example of what **NOT** to do. The Brutus Gate Spring is **NOT** meant to be stretched like you would a lighter spring for a screen door or the like. The wire is too heavy and the act of stretching it will damage your spring and possibly your gate.

