

# GATE WHEEL MOUNTING INSTRUCTIONS

## **MOUNTING INSTRUCTIONS:**

1. LOCATE GATE WHEEL ASSEMBLY ON GATE AS REQUIRED.
2. PRESS DOWN ON BRACKET ASSEMBLY TO COMPRESS THE SPRING A MINIMUM OF 1/4" (FIG. 1)
3. MAKING SURE THE SPRING IS COMPRESSED, MOUNT ASSEMBLY USING THE SUPPLIED MOUNTING SCREWS.
4. OPEN AND CLOSE GATE TO ENSURE GATE WHEEL OPERATES SMOOTHLY.

