

WEL-200

WIRELESS EDGE LINK

Frequently Asked Questions

- 1. Can the WEL-200 be used with monitored sensing edges?**
Yes, it is compatible with 8.2K and 10K edges.
- 2. Can the WEL-200 be used with non-monitored sensing edges?**
No, the edge has to include an 8.2K or 10K resistor.
- 3. How many sensing edges can be connected?**
The WEL-200 can be paired with up to 4 transmitters. A separate transmitter is required for each edge.
- 4. How many channels are provided?**
Two, each transmitter can be assigned to either channel.
- 5. What is the system's frequency?**
915 MHz band
- 6. What is the operating range?**
Up to 200 ft
- 7. Is the WEL-200 suitable for outdoor use?**
Yes, both the transmitter and receiver are housed in NEMA 4X enclosures. This allows the receiver to be mounted outside of the operator and eliminates the need for an external antenna.
- 8. What batteries should I use in the WEL-200 transmitter?**
Two AA lithium batteries (2x 1.5V), which are supplied with the unit.
- 9. What operators are compatible with the WEL-200?**
The WEL-200 works with most operators that require a 10K, NC, or Pulse input for monitored entrapment protection. Be sure to confirm with the operator manufacturer that the unit is compatible with their system.
- 10. How can I learn more?**
Contact EMX today:
Phone: 800-426-9912
Email: salesupport@emxinc.com
Web: www.emxinc.com



INDUSTRIES

EMX Industries, Inc.

4564 Johnston Parkway, Cleveland, Ohio 44128

P. 800 426 9912 F. 216 518 9884

Sales Inquiries: salesupport@emxinc.com **Technical Support:** technical@emxinc.com

www.emxinc.com