

ZND_® Assembly Guide

Basic Fence Panel Assembly

Last modified **September 2022**
please check online to confirm
you have the latest version

www.znd.com

Important Notes

Please note that this document is an assembly guide only and should be used simply to show how ZND products are assembled. The installation images contained within this document show the use of a proprietary ZND stabilizing system and this does not constitute a site specific design.



Basic Fence Panel Assembly



Suitable for:

ST612 Panel

ST812 Panel

RT612 Panel


RT812 Panel



Tube Stand
Code: 13001001



Anti-lift Bracket
Code: 09051040




Fence Coupler HD (Gripper)
Code: 08551320



Coupler Spanner
Code: 08551448










Recommended for Safety



Important Notes

Please note that this document is an assembly guide only and should be used simply to show how ZND products are assembled. The installation images contained within this document show the use of a proprietary ZND stabilizing system and this does not constitute a site specific design.

ZND_®



Important Notes

Please note that this document is an assembly guide only and should be used simply to show how ZND products are assembled. The installation images contained within this document show the use of a proprietary ZND stabilizing system and this does not constitute a site specific design.



Important Notes

Please note that this document is an assembly guide only and should be used simply to show how ZND products are assembled. The installation images contained within this document show the use of a proprietary ZND stabilizing system and this does not constitute a site specific design.

