


Installation Instructions, 56668

4" Flush Inside 45 (FI45-LS-4)




Typical Installation






56668

Installation Instructions, 56668



Suggested Tools
(others may be required)



Typical Installation & Basic Assembly