







Installation Instructions,
56668

6-8" Beam Hanger Flush (BHF-68-LS)




Typical Installation






56669

Installation Instructions, 56669



Suggested Tools

(others may be required)



Typical Installation & Basic Assembly