Superior Post & Rail Fence Installation Guide





Post Spacing & Bottom Rail Distance

All posts are 96" centers.


Fence	Bottom Rail from Ground
3 Rail	11"
4 Rail	10"

NOTE: A 2 X 4 cut to length may be used to maintain proper spacing.



Post Layout


Place stakes as necessary(changes in slope) with a string to mark the top of the post & another to mark the outside edge of the bottom of the post.





Set Post

Place posts in holes & pour concrete in the hole around the bottom of each post to 2" below ground level. Adjust posts as necessary ensuring they are level and aligned with the top string. Use aluminum post insert inside gate hinge post.





Split Rail Fence Assembly

- (a) Slide one end of the rails through the second post inserting them far enough into the post so they clear the first post.
- **(b)** Slide the rail back into the first post until the crimp engages the post.

Repeat for the other rails down the line.

