

# Battery Installation


Remove plastic strip from battery as shown in Figure A.

## IMPORTANT PLEASE READ BEFORE ASSEMBLY


To assure maximum battery contact for charging and illumination, the battery holders in your solar light are constructed in such a manner as to assure a tight fit at all times. It may be necessary for you to twist and/or turn the batteries slightly as they are inserted and also once they are in place to assure proper contact.

If your light does not appear to be working properly please try the following: (from a technological standpoint there is very little that can go wrong with this product)


- Make certain batteries are inserted properly. . .see (+) and (-) markings
- Move the batteries back and forth slightly to ensure proper contact
- Make certain that the batteries are charged (expose the solar panel on the assembled fixture to at least one full day of bright sun.)
- Replacement batteries must be AA 600mAh Ni-Cd.



**Figure A: Remove plastic strip before installing**



**Remove cover**



**Install Battery**

## **TWO-YEAR WARRANTY**

If within two (2) years from the date of purchase, this product fails due to a defect in material or workmanship, Monarch will repair or replace it, at its sole option, free of charge. This warranty applies only to the original purchaser and is not transferable.

**MONARCH WILL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.**

**THIS WARRANTY IS IN LIEU OF ALL OTHER EXPRESS OR IMPLIED WARRANTIES, INCLUDING THE WARRANTY OF MERCHANTABILITY AND THE WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY MODIFIED TO EXIST ONLY AS CONTAINED IN THIS LIMITED WARRANTY, AND SHALL BE OF THE SAME DURATION AS THE WARRANTY PERIOD STATED ABOVE. SOME STATES DO NOT ALLOW LIMITATIONS ON THE DURATION OF AN IMPLIED WARRANTY, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.**

The warranty does not apply to: (a) damage caused by accident, abuse, in handling, dropping; (b) acts of God; (c) units which have been subject to unauthorized repair, opened, taken apart or otherwise modified; (d) units not used in accordance with directions; (e) damages exceeding the cost of the product; (f) sealed lamps and/or lamp bulbs, LED's and batteries; (g) the finish on any portion of the product, such as surface scratches and/or weathering, as this is considered normal wear and tear. Some states do not allow a limitation of damages so the foregoing limitation may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

Warranty service is available by mailing postage prepaid to the authorized service station listed below. Please be sure to wrap the product securely when mailing to avoid shipping damage.

SEND DEFECTIVE PARTS TO: WARRANTY SERVICE CENTER • 3851 Revere St. • Denver, Colorado 80239 • 877.703.3412