



Attaching the Solar light to the post:

- DO NOT use any type of adhesive to attach this light. The batteries will need to be changed every 3-5 years, so you will have to remove the light in order to change them.
- Turn over the light, and remove the white tab between the battery and contact to activate light
- Set the light on top of the post
- Using a 1/8" bit on two sides of the cap, pre-drill the molding at a 90 degree angle into the post
- Using a Stainless Steel trim head screw, screw each side of the pre-drilled molding to the post
- This allows for easy removal of the light from the post, when the batteries need to be changed