


GATEMATE

LONG THROW LOCK FITTING AND MAINTENANCE INSTRUCTIONS

Tools Required:

Battery drill, Phillips driver bit, 3mm drill bit, 2mm drill bit, 26mm auger/ flat bit, tape measure, pencil, small flat head screw driver.



1. The lock should be fitted to the door or gate once it has been hung and all necessary adjustments have been made. The body of the lock should be mounted on the inside (secure side) of the gate, with just the barrel showing on the outside- to prevent any tampering with the lock. Showing the lock on the inside (secure side) of the gate.
2. Work out where you are going to mount the lock on the style of the gate, and mark the centre of the barrel position on the gate accordingly. The lock must be mounted with the cam holes in the bar facing downwards to avoid water ingress. The body of the lock should be no less than 5mm from the edges of the gate, and obviously the throw of the lock needs to reach across to secure the gate. You must also check on the other side of the gate to ensure the hole will be in a suitable position!
3. Next drill a 26mm hole in the gate with the auger or flat drill bit. Take care to ensure the hole is drilled level and straight for the best performance of the lock. Drill through until the central point of the drill bit protrudes out the back, and then finish the hole off from the back side to avoid splintering the timber.



LONG THROW LOCK FITTING AND MAINTENANCE INSTRUCTIONS



4. Now insert the lock into the hole, and test to ensure the lock will work in the situation. If it is OK level it up in line with the edge of the gate, and make marks through the fixing holes for the pilot holes.



5. Drill your pilot holes in the gate with the 3mm drill bit.



6. Put the lock back into position, and fix to the gate using the square head Philips screws, and the Philips driver bit. Once all screws are tight test the lock and ensure it turns ok- if the face of the gate is not exactly flat the lock may bind and stop it from working. If this happens you need to loosen off the appropriate screws, or insert packers until the barrel turns freely.



7. Fit the escutcheon plate on the other side of the gate. First hold it in place, and mark out the pilot holes.



LONG THROW LOCK FITTING AND MAINTENANCE INSTRUCTIONS



9. Fitting the keep. In this situation it is going on the gate post. Turn the lock to the locked position, and place the keep over the top of the bolt, allowing sufficient room for gate sag over time. Line it up straight with the edge of the gate post, and mark through the holes for drilling the pilot holes in the timber.

10. Drill the pilot holes with the 3.0mm drill bit, and fix the keep securely to the gate with the battery drill and square Philips head screws.



11. To ensure a long life from the lock you must put oil down between the bolt and the back plate at least once every 3 months - if it is situated in a coastal area, or in a high use situation, then this must be done at least every month.

GATEMATE

GATEMATE - the solution for all your gate and fencing hardware